



Reese Enterprises, Inc.

P.O. BOX 459 • ROSEMOUNT, MN 55068-0459
(651) 423-1126 • FAX (651) 423-2662
(800) 328-0953 • FAX (800) 334-8823
www.reeseusa.com

Reese 544 Frame Installation Instructions

- 1. Drill anchor holes:** The mat frames should be secured to the concrete floor using anchor bolts into lead anchors that are set into the floor
 - Drill holes in the frames at approximately 2 foot intervals for the bolts. Countersink the holes
 - Set the frames at the appropriate locations on the floor. All pieces must be held tightly together so that mitered ends are flush with each other. Mark the hole locations on the concrete.
 - Remove the frames and drill holes in the floor for the anchors
 - Install the anchors using an anchor setting tool
- 2. Secure frames:** Reinstall the frames. Secure them to the floor with 1/8" x 1 1/2" anchor bolts into the lead anchors
- 3. Install mat inside frames:** Unroll the mat, and determine how much filler should be trimmed so that mat fits snugly between aluminum frame. ***The mat is made to fit snugly into the frame according to the drawing. Reese cannot be responsible for problems that result from improperly installed frames.***
 - Trim filler an equal distance from both ends so that mat fits snugly inside frame