

Perimeter Strip

Door Jamb

804

1. Measure door frame head.
2. Cut header piece exact by category:

A) Brush: Slide the brush strip out of aluminum retainer. Cut aluminum to exact size. Using WIRE CUTTER or PLIERS cut brush to the same size.

Note: It is necessary to cut brush with a utensil that will also crimp the brush filaments. This will ensure that brush won't fall out of the retainer.

B) Door Jamb: Pull gasket slightly past the metal opposite of the side being cut to allow for a snug seal once installed.

C) Hardware Compatible: Pull gasket slightly past the metal opposite of the side being cut to allow for a snug seal once installed.

Note: Side pieces have slotted holes. Top piece has no holes and is to be drilled at the job.

3. Close the door.
4. Position header on the door stop by applying light pressure against the door.
5. Attach gasket by drilling in the center of the slot on the strip. Use screws provided to hold in place but do not tighten completely until all strips are in place.
6. Measure sides of door frame then repeat steps 2-5.
7. Tighten all screws making sure gasket has light pressure against the door.
6. Operate door to ensure part is not inhibiting the door from self-closing and latching.