



Box 459 – Rosemount, MN 55068

Phone: 800-328-0953

## Rain Drips

### R201



**Install rain drip to exterior face of the frame header. The length of the rain drip should extend at least 2” beyond the width of the door on each side. Install full width of frame header if possible.**

1. Mark hole locations making sure the top of the door clears the bottom of the rain drip.
2. Drill pilot holes for screws using a 7/64” bit.
3. Fasten screws, working from one end to the other.
4. Verify the door clearance and caulk the top of the drip strip and around each screw to prevent water penetration.