



Box 459 – Rosemount, MN 55068

Phone: 800-328-0953

Thresholds

S424



1. Measure door sill (frame width at bottom) and cut the threshold to extend the full width of the opening.
2. Notch the threshold sides if necessary to accommodate the side jamb stops.
3. Fasten on threshold to the sill with screws provided.
4. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.

Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J .17L5 9903

