



Box 459 - Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823

Sweeps

M15, M35, 64, 214,
214x261, 323, 353,
354, 362, 377, 414,
414x261, DB469, 602,
603, 701, 772, 773,
805, 806, 810, 825

1. Measure the width of the door on the butt face (the face where the hinge barrels are visible). Cut the metal retainer to this size. Leave the gasketing long enough on each end to extend out to contract the door frame. Peen the retainer so that the gasketing can not slide out of the aluminum retainer.
2. With the use of a self-closing mechanism, allow the door to close.
3. Place the sweep against the butt face of the door, lightly resting on the floor or on the bevel of the threshold it will seal against.
4. Attach with the sheet metal screws provided, locating the screw in the center of the slotted holes in the metal retainer. This permits room for adjustment later. Do not tighten the screws until all gasketing is in place.
(Note: Some parts will have round attachment holes due to the small size)
5. Tighten all the screws.
6. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested
Gasketing Materials for Fire
Doors. Intended for Application
to/with listed steel frames
and/or classified steel covered
composite, hollow metal type
fire doors rated up to 3 hours,
wood and plastic covered
composite type fire doors rated
up to 1-1/2 hours, and wood
core type fire doors rated up
to 20 minutes.

Meets UL10B, UL10C and
UBC 7-2 (1997) Category J.
17L5 9903