



Box 459 – Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823
www.reeseusa.com

Vinyl Thresholds

**1010, 1011, 1012,
1013, 1020, 1021**

1. Measure door sill (frame width at the bottom) and cut the threshold to extend the full width of opening.
2. Notch threshold sides, if necessary, to accommodate the side jamb stops.
3. Verify threshold will fit in the opening properly by setting in place and operating the door several times to ensure the part will not inhibit the door from closing.
4. Apply an adhesive designed to bond to PVC, concrete, wood, or other materials to which the threshold will be applied.
5. Replace threshold in door opening and allow proper time for the adhesive to dry before walking on threshold.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J.

17L5 9903