



Box 459 – Rosemount, MN 55068

Phone: 800-328-0953

## Sweeps – Door Shoe

### Available inserts:

**F**= Vinyl Fingers (*pictured*)

**U**= Polyurethane

**P**= Pile

### DB600



1. Measure the clearance at the bottom of the door. Measure the height of the door shoe that will be under the bottom of the door. It should be the same measurement for proper operation of the door shoe. The door will have to be trimmed, or threshold added to obtain this clearance.
2. Remove the door and measure its width.
3. Slide the gasketing material out of its aluminum retainer. Then cut the aluminum retainer to the width of the door. Trim the gasketing material to the same size.
4. Attach the metal retainer to the bottom of the door. Attach with the sheet metal screws provided, locating the screw in the center of the slotted holes in the metal retainer. This permits room for adjustment. When in position tighten all the screws.
5. Slide the gasketing back into the retainer. When the gasketing is in, peen the retainer so that the gasketing cannot slide out.
6. Reinstall the door.
7. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.

Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes.

J.17L5 9903

Meets UL10B, UL10C and CAN4-S104-2010 Category

