




Box 459 – Rosemount, MN 55068

Phone: 800-328-0953

Perimeter/Smoke-Draft

DS69



1. Measure door frame head.
2. Cut the part to extend the full width of the opening, leaving the gasketing material slightly longer than the metal retainer for a snug seal.
3. With the use of a self-closing mechanism, allow the door to close.
4. Position the gasketing material with light pressure against the door.
5. Attach with the sheet metal screws provided, locating the screw in the center of the slotted holes in the metal retainer. This permits room for adjustment later. **DO NOT** tighten the screws until all gasketing is in place. (**NOTE: some parts will have round attachment holes due to the small size**)
6. Measure the door frame sides. Attach the two side jambs in the same manner as the door frame head by repeating steps 2 through 5.
7. Tighten all the screws.
8. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.

Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for Application to/ with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes. Meets UL10B, UL10C and CAN4-S104-2010 Category J .17L5 9903

