



Box 459 - Rosemount, MN 55068  
Phone 800-328-0953  
Fax 800-334-8823

### Sweeps Brush-under door 984, 985, 986

1. Measure the clearance at the bottom of the door. Measure the height of the sweep. It should be the same measurement for proper operation of the sweep. The door will have to be trimmed or threshold added to obtain this clearance.

2. Remove the door and measure its width.

3. Slide the brush strip out of its aluminum retainer. Cut the brush to length with a WIRE CUTTER or PLIERS. Then cut the aluminum retainer to the same length.

**WARNING:** Always cut the brush strip with a WIRE CUTTER or PLIERS. This is necessary to crimp the brush filaments in the galvanized retainer to keep them from falling out.

4. Attach the aluminum retainer to the bottom of the door. Attach with the sheet metal screws provided, locating the screw in the center of the slotted holes in the aluminum retainer. This permits room for adjustment later. Do not tighten the screws until the sweep is in place.

5. Slide the brush back in the retainer. When the brush is in, peen the retainer so that the gasketing cannot slide out.

6. When in position, tighten all the screws.

7. Re-install the door.

8. Operate the door several times to insure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested Gasketing Materials for Fire Doors. Intended for application to/with listed steel frames and/or classified steel covered composite, hollow metal type fire doors rated up to 3 hours, wood and plastic covered composite type fire doors rated up to 1-1/2 hours, and wood core type fire doors rated up to 20 minutes.

Meets UL10B, UL10C  
Meets CAN4-S104-2010  
Category J.

17L5 9903