



Box 459 - Rosemount, MN 55068
Phone 800-328-0953
Fax 800-334-8823

Thresholds

V300, V301, S404, S405,
S406, S407, S408, S411,
S412, S424, S425, S426,
S427, S428, 437, S439,
S470*, S471, S472, S473,
S474*, S475, S476*, S478,
S479, 480, S481, S482*,
S483*, S484*, S485*, S486*,
S487*, S488*, S489*, S490*,
S498*

**suffix insert can be v-vinyl,
u-polyurethane, n-neoprene,
s-silicone, or pr-polyprene*

1. Measure door sill (frame width at bottom) and cut the threshold to extend the full width of the opening.
2. Notch the threshold sides if necessary to accommodate the side jamb stops.
3. Fasten on threshold to the sill with screws provided.
4. Operate the door several times to ensure the part is properly adjusted so as not to inhibit the door from self-closing and latching.



Positive Pressure Tested
Gasketing Materials for Fire
Doors. Intended for Applica-
tion to/with listed steel
frames and/or classified steel
covered composite, hollow
metal type fire doors rated up
to 3 hours, wood and plastic
covered composite type fire
doors rated up to 1-1/2 hours,
and wood core type fire
doors rated up to 20 minutes.

Meets UL10B, UL10C
Meets CAN4-S104-2010
Category J.

17L5 9903